



Lithionics Battery®

GT and GTX Series Installation Manual

*Model Numbers

GT12V450A-F24	GTX12V420A-F24
GT12V600A-F24	GTX12V525A-F24
GT24V300A-F24	GTX12V630A-F24
GT48V150A-F24	GTX12V1050A-F41
GT51V150A-F24	GTX12V1155A-F41
GT12V600A-F27	GTX12V1260A-F41
GT24V300A-F27	GTX24V315A-F24
GT48V150A-F27	GTX24V630A-F41
GT51V150A-F27	GTX51V315A-F41

*See Table 1 and 2 for model number details



NEVERDIE®
LITHIUM-ELECTRONICS = LITHIONICS BATTERY

MiniBMS®
TECHNOLOGY

OptoLoop®
TECHNOLOGY

Important Safety Guidelines

This guide contains important safety instructions for the GT and GTX Series Battery System that must be followed during installation procedures. Completely read this manual and become familiar with all system components before attempting installation. **Save this installation manual for future reference.**

The following symbols and messages are used to identify potential hazards or to clarify the procedure.



The **CAUTION** symbol indicates a hazardous situation which, if not avoided, could result in moderate or minor injury.



The **DANGER** symbol indicates a hazardous situation which, if not avoided, will result in death or serious injury.

Safety Information

1. **Before using the Battery System, read all instructions and cautionary markings on the unit, the BMS, and all appropriate sections of this manual.**
2. The information in this manual is intended for qualified personnel. Qualified personnel have training, knowledge, and experience in:
 - Selecting and using Personal Protective Equipment (PPE).
 - Installing electrical equipment.
 - Applying all applicable local and national installation codes.
 - Analyzing and reducing the hazards involved in performing electrical work.
3. Use of accessories not recommended or sold by the manufacturer may result in a risk of fire, electric shock, or injury to persons.
4. To avoid a risk of fire and electric shock, make sure that existing wiring is in good condition and that wire is not undersized. Do not operate the battery system with damaged or substandard wiring.
5. Do not operate the battery system if it has been damaged in any way.
6. This unit does not have any user-serviceable parts. Do not disassemble the battery system except where noted for connecting wiring and cabling. Attempting to service the unit yourself may result in a risk of electrical shock or fire. Internal cells remain charged after all power is disconnected.
7. To reduce the chance of short-circuits, always use insulated tools when installing or working with this equipment.
8. Remove personal metal items such as rings, bracelets, necklaces, and watches when working with electrical equipment.



HAZARD OF ELECTROLYTE VAPOR

- The battery module may emit a *non-toxic* pressurized electrolyte vapor if punctured.
- Electrolyte vapor may cause temporary minor breathing congestion.
- Electrolyte vapor can decrease visibility in closed compartments.



HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- Always turn OFF all equipment connected to the system in addition to turning OFF the power switch provided on the system to isolate the batteries from other electrical circuits, before performing any repairs or maintenance on the system.
- Do not operate the system if it has received a sharp blow, been dropped, has cracks or openings in the enclosure.
- Do not disassemble any part of the system. Internal cells remain charged after all power is disconnected.
- Do not operate the system with damaged or substandard wiring.
- Always use proper wire sizes to connect the system to inverters, chargers or other equipment.
- Voltage is present at the connector and output terminals. Always ensure that the BMS output terminals have the insulated protective boots in place.
- Always use crimped connections to connect to the output terminals.
- Always use a properly rated voltage sensing device to confirm all circuits are de-energized.



HAZARD OF HEAVY EQUIPMENT

- Use two people to lift and mount the battery module.
- Always use proper lifting techniques during installation to prevent injury.
- Do not lift the battery module by its power or signal wires as they will become damaged.

If the system is operated outside of its limits and/or used in combination with non-original components without authorization, the warranty is void.

Do not expose this unit to direct sunlight, external heat sources or submersion in any liquid. This product is designed for closed compartment use only. Damage to any part of the battery system caused from direct sunlight, external heat sources or submersion in any liquid will not be covered by the product warranty.


The Battery Module and BMS is tested to comply with UN DOT 38.3, the testing requirement for Lithium Batteries per Part III; of the UN Recommendations on the TRANSPORT OF DANGEROUS GOODS (Manual of Tests and Criteria, Fifth revised edition); [ST/SG/AC.10/11/Rev.5].

This Battery Module contains no mercury and is RoHS Compliant. Please consult your local municipal authority for proper disposal.

Consignes de Sécurité Importantes

Ce guide contient des instructions de sécurité importantes pour le système de batterie des séries GT et GTX qui doivent être suivies lors des procédures d'installation. Lisez entièrement ce manuel et familiarisez-vous avec tous les composants du système avant de tenter l'installation. **Conservez ce manuel d'installation pour référence future.**

Les symboles et messages suivants sont utilisés pour identifier les dangers potentiels ou pour clarifier la procédure.



Le mot **ATTENTION** indique une situation potentiellement dangereuse, laquelle, si elle n'est pas évitée, pourrait entraîner des blessures mineures ou modérées.



Le mot **DANGER** indique une situation dangereuse imminente, laquelle, si elle n'est pas évitée, entraînera de graves blessures, voire la mort.

Information sur la Sécurité

1. **Avant d'utiliser le système de batterie, lisez toutes les instructions et les avertissements sur l'unité, le BMS et toutes les sections appropriées de ce manuel.**
2. Les informations contenues dans ce manuel sont destinées au personnel qualifié. Le personnel qualifié possède une formation, des connaissances et une expérience en:
 - Sélection et utilisation des équipements de protection individuelle (EPI).
 - Installation d'équipements électriques.
 - Appliquer tous les codes d'installation locaux et nationaux applicables.
 - Analyser et réduire les risques liés à l'exécution des travaux électriques.
3. L'utilisation d'accessoires non recommandés ou vendus par le fabricant peut entraîner un risque d'incendie, de choc électrique ou de blessures corporelles..
4. Pour éviter tout risque d'incendie et d'électrocution, assurez-vous que le câblage existant est en bon état et que le fil n'est pas sous-dimensionné. Ne pas faire fonctionner le système de batterie avec un câblage endommagé ou de qualité inférieure.
5. N'utilisez pas le système de batterie s'il a été endommagé de quelque manière que ce soit.
6. Cet appareil ne contient aucune pièce réparable par l'utilisateur. Ne démontez pas le système de batterie, sauf indication contraire pour le câblage et le câblage. Tenter de réparer l'appareil vous-même peut entraîner un risque d'électrocution ou d'incendie. Les cellules internes restent chargées une fois que toute l'alimentation est coupée.
7. Pour réduire les risques de courts-circuits, utilisez toujours des outils isolés lors de l'installation ou de l'utilisation de cet équipement.
8. Retirez les objets métalliques personnels tels que bagues, bracelets, colliers et montres lorsque vous travaillez avec des équipements électriques.



RISQUE DE VAPEUR D'ÉLECTROLYTE

- Le module de batterie peut émettre une vapeur d'électrolyte sous pression *non toxique* s'il est perforé.
- Les vapeurs d'électrolyte peuvent causer une congestion respiratoire mineure temporaire.
- La vapeur d'électrolyte peut diminuer la visibilité dans les compartiments fermés.



RISQUE DE CHOC ÉLECTRIQUE, D'EXPLOSION OU D'ARC ÉLECTRIQUE

- Appliquer un équipement de protection individuelle (EPI) approprié et suivre des pratiques de travail électrique sûres.
- Éteignez toujours tous les équipements connectés au système en plus de désactiver l'interrupteur d'alimentation fourni sur le système pour isoler les batteries des autres circuits électriques, avant d'effectuer toute réparation ou maintenance sur le système.
- N'utilisez pas le système s'il a reçu un coup violent, s'il est tombé, s'il présente des fissures ou des ouvertures dans le boîtier.
- Ne démontez aucune pièce du système. Les cellules internes restent chargées une fois que toute l'alimentation est déconnectée.
- N'utilisez pas le système avec un câblage endommagé ou de qualité inférieure.
- Utilisez toujours des câbles de taille appropriée pour connecter le système aux onduleurs, chargeurs ou autres équipements.
- Une tension est présente au niveau du connecteur et des bornes de sortie. Assurez-vous toujours que les bornes de sortie BMS ont les bottes de protection isolées en place.
- Utilisez toujours des connexions serties pour vous connecter aux bornes de sortie.
- Utilisez toujours un dispositif de détection de tension correctement évalué pour confirmer que tous les circuits sont hors tension.



RISQUE D'ÉQUIPEMENT LOURD

- Utilisez deux personnes pour soulever et monter le module de batterie.
- Utilisez toujours des techniques de levage appropriées lors de l'installation pour éviter les blessures.
- Ne soulevez pas le module de batterie par ses fils d'alimentation ou de signal car ils seront endommagés.

Si le système est utilisé en dehors de ses limites et / ou utilisé en combinaison avec des composants non originaux sans autorisation, la garantie est nulle.

N'exposez pas cet appareil à la lumière directe du soleil, à des sources de chaleur externes ou à une immersion dans un liquide. Ce produit est conçu pour une utilisation à compartiment fermé uniquement. Les dommages à toute partie du système de batterie causés par la lumière directe du soleil, des sources de chaleur externes ou une submersion dans un liquide ne seront pas couverts par la garantie du produit.

Le module de batterie et le BMS sont testés pour se conformer à UN DOT 38.3, l'exigence de test pour les batteries au lithium selon la partie III; des Recommandations des Nations Unies sur le TRANSPORT DES MARCHANDISES DANGEREUSES (Manuel d'épreuves et de critères, cinquième édition révisée); [ST/SG/AC.10/11/Rev.5].

Ce module de batterie ne contient pas de mercure et est conforme RoHS. Veuillez consulter les autorités municipales locales pour une élimination appropriée.

1. System Specifications

1.1 Operating Specifications

Table 1 GT Series

System Model:	GT12V-450A-F24-CTRL300 External BMS	GT12V-525A-F24-CTRL300 External BMS	GT12V-600A-F24-CTRL300 External BMS	GT24V-300A-F24-CTRL300 External BMS	GT48V-150A-F24-CTRL300 External BMS	GT51V-150A-F24-CTRL300 External BMS	GT12V-600A-F27-CTRL300 Internal BMS	GT24V-300A-F27-CTRL300 Internal BMS	GT48V-150A-F27-CTRL300 Internal BMS	GT51V-150A-F27-CTRL300 Internal BMS
Capacity	450Ah	525Ah	600Ah	300Ah	150Ah	150Ah	600Ah	300Ah	150Ah	150Ah
Nominal Voltage	12.8V			25.6V	48.0V	51.2V	12.8V	25.6V	48.0V	51.2V
Recommended Charging Voltage	14.4V			28.8V	54.0V	57.6V	14.4V	28.8V	54.0V	57.6V
Maximum Charging Voltage	14.6V			29.2V	54.75V	58.4V	14.6V	29.2V	54.75V	58.4V
Overcharge Voltage Protection	14.8V			29.6V	55.5V	59.2V	14.8V	29.6V	55.5V	59.2V
Over-discharge Voltage Protection	11.6V			23.2V	43.5V	46.4V	11.6V	23.2V	43.5V	46.4V
Standard Charging Current	150A (C/3)	200A (C/3)	200A (C/3)	100A (C/3)	50A (C/3)		200A (C/3)	100A (C/3)	50A (C/3)	
Maximum Charging Current	300A (BMS Limit)			288A	144A		300A (BMS Limit)	288A	144A	
End of Charging Current	15A (C/30)	20A (C/30)	20A (C/30)	10A (C/30)	5A (C/30)		20A (C/30)	10A (C/30)	5A (C/30)	
Standard Discharging Current/Load	300A (BMS Limit)			288A	144A		300A (BMS Limit)	288A	144A	
Maximum Discharge Current/Load	300A (BMS Limit)									
System Impedance at BMS Power Terminals	2.03mΩ	1.77mΩ	2.11mΩ	1.92mΩ	5.39mΩ	5.11mΩ	2.11mΩ	1.92mΩ	5.39mΩ	5.11mΩ
Ibf Bolted Fault Current at Nominal Voltage (N4)	6,305A	7,232A	6,066A	13,333A	8,905A	10,020A	6,066A	13,333A	8,905A	10,020A
Maximum Charging Temperature Range (N1)	32 to 113°F (0 to 45°C)									
Maximum Discharging Temperature Range (N1)	-4 to 131°F (-20 to 55°C)									
Module Dimensions	24.0" x 13.0" x 11.1" (610 x 330 x 282mm)						27.0" x 16.0" x 11.1" (686 x 406 x 282mm)			
Module Weight (N2)	128lb (58.0kg)	150 (68.2kg)	160lb (72.5kg)	160lb (72.5kg)	152lb (68.9kg)	160lb (72.5kg)	178lb (80.7kg)	178lb (80.7kg)	170lb (77.1kg)	178lb (80.7kg)
BMS Case Dimensions (N3)	11.25" x 6.96" x 4.1" (286 x 177 x 104mm)						N/A			
BMS Weight (N2)	7.7lb (3.5kg)						N/A			

Table 2 GTX Series

System Model:	GTX12V420A-F24-CTRL300 External BMS	GTX12V525A-F24-CTRL300 External BMS	GTX12V630A-F24-CTRL300 External BMS	GTX12V1050A-F41-CTRL300 External BMS	GTX12V1155A-F41-CTRL300 External BMS	GTX12V1260A-F41-CTRL300 External BMS	GTX24V315A-F24-CTRL300 External BMS	GTX24V630A-F41-CTRL300 External BMS	GTX51V315A-F41-CTRL300 External BMS	
Capacity	420Ah	525Ah	630Ah	1,050Ah	1,155Ah	1,260Ah	315Ah	630Ah	315Ah	
Nominal Voltage	12.8V						25.6V		51.2V	
Recommended Charging Voltage	14.4V						28.8V		57.6V	
Maximum Charging Voltage	14.6V						29.2V		58.4V	
Overcharge Voltage Protection	14.8V						29.6V		59.2V	
Over-discharge Voltage Protection:	11.6V						23.2V		46.4V	
Standard Charging Current	210A (C/2)	262.5A (C/2)	300A (BMS Limit)				157.5A (C/2)	300A (BMS Limit)	157.5A (C/2)	
Maximum Charging Current	300A (BMS Limit)									
End of Charging Current	21.0A (C/20)	26.25A (C/20)	31.5A (C/20)	52.5A (C/20)	57.75A (C/20)	63A (C/20)	15.75A (C/20)	31.5A (C/20)	15.75A (C/20)	
Standard Discharging Current/Load	300A (BMS Limit)									
Maximum Discharge Current/Load	300A (BMS Limit)									
System Impedance at BMS Power Terminals	2.83mΩ	2.77mΩ	2.31mΩ	3.94mΩ	3.57mΩ	3.28mΩ	2.83mΩ	3.91mΩ	5.66mΩ	
Ibf Bolted Fault Current at Nominal Voltage (N4)	3,689A	4,621A	5,541A	3,249A	3,585A	3,902A	9,046A	6,547A	9,046A	
Maximum Charging Temperature Range (N1)	32 to 131°F (0 to 55°C)									
Maximum Discharging Temperature Range (N1)	-4 to 131°F (-20 to 55°C)									
Module Dimensions	24.0" x 13.0" x 11.1" (610 x 330 x 282mm)			41.0" x 13.38" x 12.85" (1041 x 340 x 326mm)			24.0" x 13.0" x 11.1" (610 x 330 x 282mm)	41.0" x 13.38" x 12.85" (1041 x 340 x 326mm)		
Module Weight (N2)	134lb (60.8kg)	139lb (63.0kg)	144lb (65.3kg)	275lb (124.7kg)	285lb (129.3kg)	295lb (133.8kg)	144lb (65.3kg)	302lb (137.0kg)	302lb (137.0kg)	
BMS Case Dimensions (N3)	11.25" x 6.96" x 4.1" (286 x 177 x 104mm)									
BMS Weight (N2)	7.7lb (3.5kg)									

Notes for Table 1 and 2:

(N1) Maximum charging and discharging rates apply depending upon the ambient temperature and duty cycle of the system. UL1973 tests of maximum charge and discharge current were performed at 25°C/77°F.

(N2) Does not include 4/0 power cable's weight as its length varies per application.

(N3) Does not include 4/0 power cable, main power connector, or terminals. Please see www.lithionicsbattery.com for dimensions.

(N4) "Bolted Fault Current" per NFPA-70E. See section 1.2 for details.

1.2 Arc Flash Energy Specifications

- An arc flash is the light and heat produced from an electric arc supplied with sufficient electrical energy to cause substantial damage, harm, fire, or injury.
 - An example of an arc flash event could be a direct short circuit caused by a metallic object such as a tool bridging between the positive and negative of an energized circuit.
 - Table 3 below quantifies the hazard level of arc flash energy that each battery system is capable of producing.

Per NFPA 70E D.5.1 "Maximum Power Method"

$$I_{arc} = 0.5 \times I_{bf}$$

$$IEm = 0.01 \times V_{sys} \times I_{arc} \times T_{arc} / D^2 \text{ (Arc Flash Energy)}$$

Table 3

Tarc= 70mS fuse clearing time	Configuration	Vsys	Impedance mΩ	Ibf, calc.	Iarc	IEm cal/cm ²	3x IEm cal/cm ²	Distance where IEm=1.2 (Arc Boundary), inches.	Hazard level
	GT12V450	12.8	2.03	6305	3153	0.014	0.041	2	0
	GT12V525	12.8	1.77	7232	3616	0.016	0.047	2	0
	GT12V600	12.8	2.11	6066	3033	0.013	0.039	2	0
	GT24V300	25.6	1.92	13333	6667	0.058	0.173	4	0
	GT48V150	48	5.39	8905	4453	0.072	0.217	4	0
	GT51V150	51.2	5.11	10020	5010	0.087	0.260	4	0
	GTX12V420	12.8	3.47	3689	1844	0.008	0.024	1	0
	GTX12V525	12.8	2.77	4621	2310	0.010	0.030	1	0
	GTX12V630	12.8	2.31	5541	2771	0.012	0.036	2	0
	GTX12V1050	12.8	3.94	3249	1624	0.007	0.021	1	0
	GTX12V1155	12.8	3.57	3585	1793	0.008	0.023	1	0
	GTX12V1260	12.8	3.28	3902	1951	0.008	0.025	1	0
	GTX24V315	25.6	2.83	9046	4523	0.039	0.117	3	0
	GTX24V630	25.6	3.91	6547	3274	0.028	0.085	3	0
GTX51V315	51.2	5.66	9046	4523	0.078	0.235	4	0	

Hazard/risk classification as per NFPA 70E-2000

Category	Energy Level	Typical PPE Examples
0	N/A	Non-melting, flammable materials (e.g. untreated cotton, wool, rayon, etc.)
1	5 cal/cm ²	FR shirt and FR pants
2	8 cal/cm ²	Cotton underwear plus FR shirt & pants
3	25 cal/cm ²	Cotton underwear plus FR shirt & pants plus FR coverall
4	40 cal/cm ²	Cotton underwear plus FR shirt & pants plus double layer switching coat and pants

1.3 Manufacturing Date Code Format

- MMDDYYYY001
 - MM: Month of Manufacture
 - DD: Day of that Month
 - YYYY: Year of Manufacture
 - 001: Sequence of Battery Produced on That Day
- Example: 01012020001 = manufactured on January 1, 2020 and it was the first battery produced on that day.

2. System Installation

2.1 Short Circuit Protection

- The battery system must be protected by a DC fuse. The models listed in this document were evaluated and tested by Underwriter Laboratories with external fuses as noted. UL Listed Class J or Class T Fuse, rated 350A (450A for GTX Series). The fuse is to be provided downstream of the BMS before the load or supply in all cases. The fuse should be used with a UL Listed fuse holder. The use of any other fuse or non-fuse voids the UL Listing of the models.
- Examples of approved:
 - Fuse: Littelfuse JLLN-350 or Eaton DFJ-300
 - Fuse holder: Littelfuse LFT30400 or Eaton JM60400-1CR-1
 - Fuse placement must be directly after the positive power terminal on the BMS. (Fuse placement may be controlled by other industry standards such as ABYC or RVIA.)

2.2 Disconnect Device Protection (only applies to GT51V150A and GTX51V315A systems)

- Per UL1973 Revision 2 Section 7.8.1.4, the GT51V150A and GTX51V315A systems must have 2 additional disconnect devices, one located on the positive pole and one on the negative pole.
 - The disconnect devices shall not require the use of special tools or equipment to be operated.
 - Recommended disconnect device: Gigavac HBD41 Hermetic Battery Disconnect.
 - Please see Figure 1 for the disconnect devices placement.

2.3 Battery Module and NeverDie BMS Unit Environment and Mounting orientation

- The Battery Module and BMS Unit should be mounted in an environment that does not receive direct sunlight, pressurized water or road debris.
- To avoid power interruption, your installation may need to consider controlling the ambient operating temperature.
- Mount the Battery Module in an upright position, i.e. black lid faces up.
 - Other orientations are NOT permitted and will void the warranty.
- The BMS Unit can be mounted in any orientation as long as all its features are accessible.
- Ensure that the BMS Unit is located in close proximity to the Battery Module so that all connectors can be mated in the following steps.

2.4 Temperature Sensor Connector

- The temperature sensor cable and connector exiting the battery module must be connected to the BMS.
- Connect the two M8 circular connectors together by first aligning their pins and pressing them together, then rotate the securing nuts until they stop snugly.
- **Do not use the temperature probe from the inverter-charger manufacturer.**

2.5 Main Power Connector

- The battery module has a large black female main power connector that must be inserted into the BMS' male main power connector. This is the connector with the large 4/0 red and black wires and single small gauge gray cable.
- Align the connectors and insert them together.
- Use 2 zip ties to bind the connectors together so that they may not separate during use.

2.6 NeverDie BMS Unit Power Terminals

- Connect the BMS Unit Power Terminals to your DC bus, both Positive (Red) and negative (Black).
 - Use correctly sized wire conductors for the application.
 - Torque to 80 INCH pounds
 - Never stack ring terminals.
 - Never place the stainless-steel washer between the Power Terminal and ring terminal lug (see Figure 1 on Page 7).

2.7 Pressure Vent

- It is recommended to install a ventilation hose onto the pressure vent barb when the Battery Module is in a location with poor ventilation.
 - The hose shall direct the gases to the atmosphere.

2.8 BMS Unit I/O Connector

- Some systems have a rectangular I/O connector to extend the BMS Unit features remotely such as remote Power/Reset switch, LED indicator, or serial datalogging. Be sure to connect the I/O connector if so equipped.

2.9 Initial Charge Cycle

- Initially the system must be FULLY charged once to calibrate the BMS Unit to the Battery Module. Please read and follow the next section to perform this.

3. System Operation

3.1 Powering the System On

- Short-press the Power switch for 1 second.
 - The switch will illuminate once power is enabled.
 - You may notice an audible “thunk” noise of the internal contactor switching on.
 - Check that there is voltage at the Power Terminals with a voltmeter.

3.2 Powering the System Off

- Long-press the Power switch for 3 seconds.
 - The switch will cease to illuminate once power is disabled.
 - You may notice an audible “thunk” noise of the internal contactor switching off.
 - Check that there is 0V at the output terminals with a voltmeter.

3.3 Charging

- The charging device(s) connected to the Lithium Battery System must be programmed as per Table 1.
- Charging may be performed at any time the system is powered On.
 - **NOTE** – The Lithium Battery System will disconnect power if the voltage, amperage, or temperature limits are exceeded during charging.
 - Only use a Lithionics Battery approved charging source. Please contact Lithionics Battery for charger approval.

3.4 Initial Charging Cycle

- The initial charging cycle is required as it calibrates the NeverDie BMS to the Battery Module for accurate State of Charge percentage (SoC) monitoring.
- During the initial charging cycle, the system must reach a voltage level that is equal to the Standard Full Charging Voltage indicated in Table 1.
- Enable the charging device(s) so that they may complete a charge cycle. It is recommended to not have any discharge loads active during the initial charging cycle, especially towards the end of charging.

3.5 Discharging

- Discharging may be performed at any time the system is powered On.
 - **NOTE** - The Lithium Battery System will disconnect power if the voltage, amperage, or temperature limits are exceeded during discharging.
- The NeverDie feature allows the system to have a “reserve” amount of energy left in the battery. Once the system is discharged to 12.0V or 10% State of Charge (SoC), whichever comes first, power will be disabled to leave a “reserve” amount of energy still left in the battery.
- To enable the remaining reserve energy of the system, short-press the Power switch for 1 second.
 - **NOTE** - Once the reserve range is enabled the battery should be charged as soon as possible.
 - **WARNING** - If the reserve energy is used and the battery module is left in a deeply discharged state without immediate charging, the battery module will become permanently damaged.

3.6 System Storage Procedure

- Storing your battery at the correct specifications is important as it keeps the battery in the healthiest state possible for the fastest deployment when needed.
- If the Lithium Battery System will not be in use for greater than 2 weeks, it is recommended to enable system storage.
- Storage mode is simply a fully charged system in the Powered Off state.
- To enable System Storage:
 - Perform a full charge cycle, ensure that the System voltage reaches the Standard Full Charging Voltage indicated in Table 1.
 - Power off the System, long-press the Power switch for 3 seconds. Check that the switch is no longer illuminated. Check that there is 0V at the Power Terminals with a voltmeter.

Table 3

Storage Temperature & Humidity Range	< 1 Month	-4~95°F (-20~35°C), 45~75%RH
	< 3 Months	14~86°F (-10~30°C), 45~75%RH
Long Term Storage	If the battery needs to be stored for > 3 months the voltage should be 13.2V for a 12V battery (or 3.3V x number of cells in series) (~50%SOC) and stored at the recommended storage specifications shown above. Additionally, the battery needs at least one charge-discharge-recharge to 50% SOC cycle every six months.	
Self-discharge rate	≤3% per month	

Storage conditions < 3 months:

1. Fully charge the battery.
2. Turn the battery **OFF** by the Power/Reset switch.
3. Store the battery in an environment according to the specifications shown above.

Storage conditions > 3 months:

1. Reduce the battery SOC to 3.3V/cell which is 50% ±10% SOC.
NOTE - See table 4 below for voltage calculation.
2. Turn the battery **OFF** via the Power/Reset switch.
3. Store the battery in an environment according to the specifications shown in table 3 above.
4. Every 6 months charge the battery to 100% SOC, then discharge the battery to LVC, then charge it to 50% ±10% SOC.

Table 4

Battery Voltage	Number of Cells	~50% SOC Voltage
12V	4	13.2
24V	8	26.4
48V	15	49.5
51V	16	52.8

NOTE – For further system installation and operation please refer to the *Advanced Series User Guide* available at: <http://www.lithionicsbattery.com/user-guides/>

Figure 1: System Example

